








HEAT KITCHEN

Aufbauanleitung | Assembly Instruction


HEAT KITCHEN




18.213.22
18.213.23




2



3





HEAT KITCHEN




18.410.24
18.410.25

18.410.26
18.410.27







18.213.21












2






18.213.22





1

2






3








18.410.28
18.410.29





4x




1




2







18.410.30
18.410.31









18.410.30
18.410.31




2








3




4










HEAT KITCHEN





11 — 12 — 13

18.213.19
18.213.20
18.213.35








R





L






18.904.76







OUTDOORCHEF.COM



Outdoorchef AG | Eggbühlstrasse 28 | Postfach | 8050 Zürich | Switzerland
Outdoorchef Deutschland GmbH | Wickerer Weg 13-15 | 65719 Hofheim am Taunus | Germany

HEAT KITCHEN | OKTOBER 2024